


Quick Start Guide

KP806




Xiamen Hanin Electronic Technology Co.,Ltd


ADD: Room 305A,Angye Building,Pioneering Park,
Torch High-tech Zone,Xiamen,China.
TEL: +86-(0)592-5885993
FAX: +86-(0)592-5885992
WEB: www.hpert.com

Appearance and components


■ Front View



■ Rear View




■ Open the Top Cover



Packing List

■ Standard Accessories



Printer



AC Adapter



Power Cord




CD



Quick Start Guide



USB Cable



Waterproof Cover



Ethernet Waterproof Buckle
(Without Ethernet line)




Roll Paper

■ Optional Accessories




Beam Cover




Wall Hanging loading

Ethernet Waterproof Buckle Loading


1. Let Ethernet line get through lid of waterproof net.




2. Open silicone lid of waterproof net, set silicone lid into waterproof net.




3. Adjust incision of silicone lid of waterproof net and top cover of waterproof net, to suit for crystal shrapnel of Ethernet.




4. Let silicone of top of waterproof net and crystal head into lid of waterproof net, to make sure lid of waterproof net is plugged tightly.




5. Let Ethernet into the base of waterproof net, press buckle till it into right position.



3. Pull out some roll paper, and close the printer cover.




4. Tear the extra paper in the direction of printer.




Paper Loading

1. Press the cover open button to open the printer cover.



2. In the correct direction of the roll paper, install the roll paper.



Power Supply

1. Make sure the printer is "OFF".

2. Connect AC adapter with printer.

3. Connect AC adapter with power cord.

4. Plug the other side of power cord into the socket nearby.

